

DERMASOFT KLG LIQ

DERMALENE KLG LIQ is an agent that noticeably improves penetration of most direct and acid dyes, without affecting perspiration, water and washing fastness.

TYPICAL ANALYSIS

Appearance	Clear yellow liquid
Chemical constitution	Nitrogenous condensation product
Water solubility	Soluble
pH (10 g/l)	7.0÷9.0

PROPERTIES

DERMALENE KLG LIQ enables the use of a number of dyes to meet the requirements of wet fastness for shoes, where a full penetration is necessary, and for garment leather as well.

It has practically no adverse effects on the hand character of the resulting leather and does not significantly affect the shade of dyeings, and on the light fastness or rubbing fastness of the resulting leather as well.

APPLICATION

The amounts to be used are generally from 0.5 % to 2.0 % based on shaved weight.

When correctly stored, it is stable 36 months.

This sheet is a synthetic illustration of the product to enable the user to employ it at the best.

Properties and values are not, therefore, sales specifications.

Taking into account the several possibilities of application of this product, no warranty of the results is possible.

Expiry date refers to the product well closed in the original container, in fresh and dry area. Some particularly sensitive products, when open, should be used rapidly.

Stir well before using the product, close tightly the container to preserve the properties.

Our technical service is at your disposal for any recommendation.