## **DERMALENE XL LIQ**

DERMALENE XL LIQ is a sulphone based replacement syntan with good astringency.

## TYPICAL ANALYSIS

Appearance	brown liquid
Total solids	$50 \pm 3$ %
pH (10 % solution)	$2.5 \pm 1.0$

## PROPRIETÀ

DERMALENE XL LIQ, due to its good bleaching action on chrome leathers, is recommended for white leathers, where its use will promote a soft, full feel with good white, lightfast, colour. The resulting leather may be dyed with good level results.

Moreover, DERMALENE XL LIQ is also recommended for the production of shrunken grain leathers on all skin types. Its use will produce leathers with shrink pattern of good uniformity, and the effect can be varied from a fine pattern to a medium/large pebbled grain.

## APPLICATION

Recommended amounts are generally ranging from 3 to 10 %.

Properties and values are not, therefore, sales specifications.

**Stir well before using the product, close tightly the container to preserve the properties.** Our technical service is at your disposal for any recommendation.

When correctly stored, it is stable 12 months.

This sheet is a synthetic illustration of the product to enable the user to employ it at the best.

Taking into account the several possibilities of application of this product, no warranty of the results is possible. **Expiry date refers to the product well closed in the original container, in fresh and dry area.** Some particularly sensitive products, when open, should be used rapidly.